

STEPPERONLINE[®]

User Manual

DBLS-01S

Brushless DC Motor Driver



©2021 All Rights Reserved

Read the operating instructions carefully before putting the driver into operation with power

1. Summary

This brushless motor driver is a driver independently developed by STEPPERONLINE to cooperate with the field of modern industrial automatic control. It mainly uses high-performance dedicated brushless DC motor driver chips, which have high integration, small size, complete protection, simple and clear wiring, and high reliability. The driver is suitable for driving small and medium-sized brushless DC motors with a rated power below 200W. The driver adopts a new type of PWM technology to make the brushless motor run at high speed, low vibration, low noise, good stability and high reliability.

2. Features

- High performance and low price
- PID speed, current double loop regulator
- 20KHZ chopper frequency
- 2 times overloading capacity
- Build with over-voltage, under-voltage, over-current, over-temperature, Hall signal illegal and other error alarm functions

3. Electrical indicators

Driving voltage: 9~55VDC, recommend voltage: 24VDC-48VDC

Input voltage	24VDC	36VDC	48VDC
Continuous output current	8.3A	5.5A	4.2A
Max. output power	200W	200W	200W
Peak output current	13A/3S	13A/3S	13A/3S

The constant of Acceleration time: Default:1 second, others can be customized, please check with technical support.

Note:

This product is a professional electrical equipment and should be installed, debugged, operated and maintained by professional and technical personnel. Improper use will cause electric shock, fire, explosion and other dangers.

This product is powered by a DC power supply, please confirm that the positive and negative poles of the power supply are correct before powering on.

Do not plug or unplug the connecting cable when the power is on, and no short-circuiting of the cable is allowed when the power is on, otherwise the product will be damaged.

If the motor needs to change direction while it is running, it must first decelerate till stop, and then change direction.

The driver is a power device, try to keep the heat dissipation and ventilation of the working environment.

Terminal Interface Description

1) Power Input

No.	Terminal Name	Description
1	V+	24VDC~48VDC input
2	GND	GND input

2) Motor Input

No.	Terminal Name	Description
1	MA	Motor A phase
2	MB	Motor B phase
3	MC	Motor C phase
4	GND	GND
5	HA	Hall signal A phase input
6	HB	Hall signal B phase input
7	HC	Hall signal C phase input
8	+5V	Hall signal power line


3) Control Signal

No.	Terminal Name	Description
1	GND	Signal ground
2	F/R	CW/CCW terminal
3	EN	Stop/Start terminal
4	BK	Brake terminal
5	SV	Analogy signal input terminal
6	PG	Speed output terminal
7	ALM	Alarm output terminal
8	+5V	+5V power output terminal

Built-in potentiometer R-SL: Adjust the motor speed gain, which can be adjusted from 0~100%.

Built-in potentiometer R-CS: Maximum protection current setting, built-in potentiometer can be set 0%~100% continuous current protection.

4. Machine installation drawings:



5.Function and Usage

Speed adjustment method

The driver offers the following three speed adjustment methods, one of which can be selected by the user as follows:

Inner potentiometer speed adjustment: turn the potentiometer on the drive panel counterclockwise to reduce the motor speed and clockwise to increase it. The potentiometer must be set to minimum when the user uses an external input for speed adjustment.


External input speed adjustment: connect the two fixed terminals of the external potentiometer to the GND and +5v terminals of the driver respectively, and connect the adjustment terminal to the SV terminal to adjust the speed using the external potentiometer (10K~50K), or through other control units (e.g. PLC, microcontroller, etc.) to input the analogue voltage to the SV terminal to achieve speed adjustment (relative to GND), the SV port accepts a range of DC 0V~+5V, corresponding to the motor rotation speed of 0~rated speed.

An external digital signal can also be used to regulate the speed: A pulse width digital signal (PWM) with an amplitude of 5V and a frequency of 1KHz to 2KHz can be applied between SV and GND for speed adjustment, and the motor speed is adjusted linearly according to the duty cycle. In this case, the SV digital signal amplitude can be attenuated by adjusting the R-SL potentiometer by a ratio of 0 to 1.0, usually by setting the R-SL to 1.0. No attenuation is applied to the SV input digital signal.

The motor speed can also be changed by command via communication method.

Built-in potentiometer speed control wiring diagram

Currently the driver has 2 versions, V2.0 and V2.4. For V2.0 Version, motor runs when the terminal is switched on and conversely the motor stops. While for V2.4 version, motors only runs when the terminal is switched off and conversely the motor stops.



Motor run/stop control (EN)

The motor can be controlled to run and stop by controlling the switch-on and switch-off of the terminal EN in relation to GND. Currently the driver has 2 versions, V2.0 and V2.4.

For V2.0 Version, motor runs when the terminal is switched on and conversely the motor stops.

While for V2.4 version, motors only runs when the terminal is switched off and conversely the motor stops. When the motor is stopped using the run/stop terminal control, the motor is stopped naturally. The law of motion is related to the load inertia.

Motor forward/reverse control (F/R)

The direction of motor operation can be controlled by controlling the connection of terminal F/R to terminal GND. When F/R and terminal GND are not switched on, the motor runs clockwise (facing the motor shaft), and vice versa, the motor runs counterclockwise. To avoid damage to the drive, when changing the motor steering, the motor should be stopped before operating to change the steering. Changing the direction of operation while the motor is running should be avoided.

Braking stop (BK)

The braking stop of the motor can be controlled by the connection of control terminal BK to terminal GND. When control terminal BK is disconnected from terminal GND, the motor runs, when it is switched on the motor quickly brakes to a stop, braking stop is faster than natural stop, the specific stopping time is related to the load inertia of the user's system.

Attention: As the brake stop has a bad impact on both the electrical and the mechanical, a natural stop should be used if there are no special stopping requirements.

Motor speed signal output (PG)

The speed pulse output is a 5V pulse output, to obtain the signal a pull-up resistor of 3K ohm ~10K ohm should be connected to the power supply. The number of output pulses per revolution of the motor is $3 \times N$, N being the number of pairs of poles of the motor. For example: 2 pairs of poles, i.e. a four-pole motor, 6 pulses per revolution. When the motor speed is 500 rev/min the output pulse of the terminal PG is 3000.


Alarm output (ALM)

Alarm output of the driver: this terminal is low during an alarm. To obtain a signal, a pull-up resistor of 3K ohm to 10K ohm should be connected to the power supply. When the alarm is on, this terminal is connected to GND (low level) and the driver stops itself and is in alarm.

Drive fault

If a fault occurs inside the driver such as overvoltage or overcurrent, the driver enters a protection state, the driver will automatically stop working, the motor stops and the red light on the driver is always on. The driver can only disarm the alarm if the enable terminal is reset (i.e. EN is disconnected from GND) or if power is cut off. Please check the motor wiring or remove the load if this fault occurs.

Connection Diagram of brushless motor and driver



6. Communication Method

The communication mode is based on the standard Modbus protocol, in accordance with the national standard GB/T 19582.1-2008, and is based on the RS485 two-wire serial link communication, the physical interface uses the conventional 3-pin 2.54 terminal (A+, GND, B-), the serial connection is very convenient. Transmission mode RTU, validation mode CRC, CRC start word FFFFH, data mode 8-bit asynchronous serial, 1 stop bit, no validation bit, communication baud rate (9600), other baud rates can be customized.

Function parameter support 03H multi-register read, 06H single register write.

Site address: 00: Broadcast address

1-250: User address

251-255: Special address, not available to users

No.	address	name	Setting range	Default	unit	
00	\$8000	First byte: control bit state Second byte: Hall angle and number of pole pairs of motors	First byte: Bit0: EN Bit1: FR Bit2: BK Bit3: NW Bit4: MDX Bit5: X12 Bit6: KH Second byte: Bit0-3: number of pole pairs 1-15 Bit4-7: hall angle 0:120	00H 04H		
01	\$8001	Maximum speed for analogue speed regulation	0-65535	6000	RPM	Jumper cap control
02	\$8002	First byte: start torque Second byte: sensorless start speed	1-255 1-255	40H 04H		
03	\$8003	First byte: acceleration time Second byte: deceleration time	1-255	0 0	0.1s	
04	\$8004	First byte: maximum current Second byte: model		90H 0FH		144 corresponds to 13A 15 Sensored, 16: sensorless
05	\$8005	Communication speed setting	Closed loop: 0-65535 Open loop: 0-255	2000 81%	RPM	
06	\$8006	Braking force	0-1023	1023		
07	\$8007	First byte: site address Second byte: reserve	1-250	1 0		
10-17		\$8010-\$8017	reserve			
18	\$8018	Actual motor speed				Return value hexadecimal to decimal multiplied by 20 divided by the number of motor poles
1B	\$801B	First byte: fault state Second byte: motor running state	Bit0: locked rotor Bit1: overcurrent Bit2: hall value abnormal Bit3: Bus voltage too low Bit4: Bus voltage too high Bit5: Current peak alarm Bit6: reserve Bit7: reserve			
1C		\$801C-\$801F	Reserve			
20		Over \$8020 illegal				

Adress 8000H-8017H are read and write registers

Adress 8018H-801FH are read-only registers

Other addresses are illegal

8000: First byte:

EN:At NW=0, 0: external EN low valid 1: external EN high valid

At NW=1, 0: EN not valid 1: EN valid

FR: at NW=0, 0: external FR low valid 1: external FR high valid

At NW=1, 0: FR not valid 1: FR valid

BK: at NW=0, 0: external BK low valid 1: external BK high valid

At NW=1, 0: BK not valid 1: BK valid

NW	MDX	X12	Function
0	0	X	External analog speed
1	X	X	Internal communication control

KH: 0: Speed closed-loop mode 1: Speed open-loop mode

2 pole pair start 01 06 80 00 09 02 27 9B

Write speed 1000 01 06 80 05 E8 03 BE 0A

Write speed 1500 01 06 80 05 DC 05 28 C8


Natural stop 01 06 80 00 08 02 26 0B

Braking stop 01 06 80 00 0D 02 25 5B

7. Communication Wiring Method

RS-485 communications can be made by driving a conventional 3-pin 2.54 wiring port device.

The pinout of the conventional 3-pin 2.54 wiring port is defined as follows:



Pin	Function
1	A
2	GND
3	B