

#### High-end Type





#### **FEATURES**

- Universal 85 277VAC or 120 390VDC Input voltage
- Operating ambient temperature range: -40°C to +85°C, full load at 60°C
- High efficiency, high reliability
- Transient peak current function: 6 times rated current for 15ms
- Up to 200% (PN) dynamic power for 5s
- Continuous static power margin of up to 125% (PN)
- Support 5+1 bus high precision parallel current sharing
- Active PFC, PF>0.98
- Support DC OK, AC OK, remote control function
- Support ModBus communication protocol
- Double-sided conformal coating, salt-spray proof, explosion-proof
- Operating altitude up to 5000m
- OVC III (design refer to EN62477, 2000m)
- 5 years warranty
- Output short circuit, over-current, over-voltage, over-temperature protection, input under voltage protection
- Safety according to ATEX, IECEx increased safety type explosion-proof certification
- Safety according to ANSI/ISA 71.04-2013 G3
- Safety according to IEC/EN/UL/BS EN62368, GB4943, IEC/EN/UL61010, EN61558, EN62477, IEC60079, GB3836, NB/T31017

LIHF240-23Bxx series is Mornsun explosion-proof Din-rall power supply featuring with energy saving, high performance, high reliability, high efficiency. With 200% peak load capacitity is enough to support heavy loads such as DC motors or capacitive loads, up to 95% efficiency can greatly improve power supply reliability and service life. With good EMC performance and compliant with international standards of IEC/EN/UL/BS EN62368, GB4943, IEC/EN/UL61010, EN61558, EN62477, IEC60079, GB3836, NB/T31017 for EMC and safety. The power supply meets the "ec" increased safety and "nC" isolation short-circuit n-type explosion-proof certification and is suitable for explosive environment where the equipment protection level is Gc in zone 2. It is widely used in wind power industry, ships, DCS, industrial control equipment, imachine control, instrumentation, LED, power, security, 5G communication, new energy and other industries.

Selection Guide								
Part No.*	Output Power (W)	Nominal Output Voltage and Current (Vo/Io)	Output Voltage Adjustable Range (V)	Efficiency at 230VAC (%) Typ.	Max. Capacitive Load (µF)			
LIHF240-23B24	240	24V/10A	24-28	94.5	50000			
LIHF240-23B48	240	48V/5A	48-55	95	25000			
Note: *When the output voltage rises, the total power of the product should not exceed the rated power.								

Input Specifications							
Item	Operating Conditions	Min.	Тур.	Max.	Unit		
Input Voltage Range	Rated input (Certified voltage)	100		240	\/AC		
	AC input	85		277	VAC		
	DC input	120		390	VDC		

**MORNSUN®** 

#### LIHF240-23Bxx Series



Maximum Input Voltage	Lasts for 2h without damage			305	VAC	
Input Voltage Frequency			47		63	Hz
Input Switching Voltage			65		80	\40
Input Turn-off Voltage			55		70	VAC
I + O	115VAC				3	
Input Current	230VAC				1.5	
l	115VAC	Cold start		10	-	A
Inrush Current	230VAC			15		
D Ft	115VAC		0.98			
Power Factor	230VAC		0.95			
THD	115VAC, rated load			3.5		%
Start-up Delay Time	115VAC/230VAC, rated load				2000	ms
Input Fuse	Built-in fuse			8		Α
Hot Plug				Unavo	ailable	

<b>Output Specifications</b>	3							
Item	Operating Conditions			Min.	Тур.	Max.	Unit	
Output Voltage Accuracy	Full load range	•		-	±1.0			
Line Regulation	Rated load				±0.25		%	
Load Regulation	0% - 100% load	k			±0.5	-		
D	000) (4.0		24V		13.9		147	
Power Consumption*	230VAC, rated	load	48V		12.6		W	
	20MHz bandw	idth,	24V			80		
Ripple & Noise*	peak-to-peak	value	48V			120	mV	
Hold-up Time	115VAC/230VA	4C		20		-	ms	
DC OK Signal	Resistive load			30VDC/1A Max.				
Short Circuit Protection					Hiccup mode, constant current operation(constant current time adapts with different load conditions), output off for 5s, long-term short-circuit protection, self-recover			
Static power				125%lo (typ.), work for a long time at room temperature				
Dynamic power	115VAC/230VA	AC		200% lo working 5s (min.), the off time adapts with different load conditions, long-term protection, self-recover				
Transient Peak Current Function				600% lo working 15ms 3 times (typ.), long-terr short-circuit protection, self-recover			-	
Over veltere Pretection	24V			\$35VDC (Output-off or clamping, self-recover)				
Over-voltage Protection	48V		≤60VDC (C	utput-off or	clamping, se	lf-recover)		
	230VAC,	Over-ter	nperature protection start	-		95	•0	
Over-temperature Protection*	rated load, self-recover	Over-ter	nperature protection release	60			℃	

Note: 1. \*The \*Tip and barrel method" is used for ripple and noise test, output parallel 47uF electrolytic capacitor and 0.1uF ceramic capacitor, please refer to Enclosed Switching Power Supply Application Notes for specific information;

<sup>3. \*</sup>Power consumption curve, over-current protection mode and short circuit protection mode see product characteristic curve.

General Specifications							
Item		Operating Conditions	Min.	Тур.	Max.	Unit	
	Input - 😩	Electric strength test for 1min., leakage current <5mA (Isolation Test for ⓐ need to remove the screw at the mark	2500				
Isolation Test*	Input - output		4000	-	_	VAC	
	Output - 😩	shall (*) *)	500	_			

**MORNSUN®** 

<sup>2. \*</sup>Over-temperature protection: Put the product into a high temperature box. After the ambient temperature stabilizes, increase the temperature slightly (3°C to 5°C), and the load remains unchanged. After the product reaches thermal equilibrium, increase the temperature until the product triggers over-temperature protection;

#### LIHF240-23Bxx Series




	Input - 😩	Environment temperature: $25\pm5^{\circ}$							
Insulation	Input - output	Relative humidity: < 95%,			500			<b>M</b> Ω	
Resistance	Output - 😩	Test voltage: 500VDC					-		
Operating Ter	mperature				-40		+85		
Storage Temp	perature				-40	-	+85	$^{\circ}$	
Operating Hu	ımidity	Non condensing			10		95	0/ DL I	
Storage Humi	idity	Non-condensing			20		90	%RH	
O dhabina Tra		PFC			60		70		
Switching Fre	quency-	DC-DC			40	-	130	kHz	
			-40℃ to -30℃		2				
		Operating temperature derating @AC input	+60°C to +75°C		2.5			-	
			+75℃ to +85℃	25CFM	2.25	-	-	-	
D		Operating temperature derating @DC input	-40°C to -30°C		2			<b>%/</b> ℃	
Power Deratir	ng		ture +60°C to +75°C		2.5				
			+75℃ to +85℃	25CFM	2.25		-		
			85VAC - 100VAC		1			%/VAC	
		Input voltage derating	120VDC - 140VDC		1			%/VDC	
Leakage Cur	rent	240VAC	Touch current			<0.5mA			
Safety Standard					IEC/EN/UL6 EN62477-1,	1010-1, GB4 IEC60079-0,	UL/BS EN6236 943.1, EN6155 IEC60079-7, II ANSI/ISA 71.04	58-1 <i>,</i> EC60079-15,	
Safety Class MTBF					CLASS I				
		MIL-HDBK-217F@25℃			>702,000h				
		MIL-HDBK-217F@40°C			>524,000h				
OVC					III				
Warranty		Ambient temperature: </td <td><b>10</b>℃</td> <td></td> <td>5 years</td> <td></td> <td></td> <td></td>	<b>10</b> ℃		5 years				
High and Low	/ Voltage Crossing	It needs to be test with M	lornsun UPS (TBD)		NB/T 31111-	-2017			

Note: 1.\* ①Remove the screw at the mark when the product is subjected to withstand voltage test; ② The gas discharge tube built into the device effectively protects the power supply against damage by asymmetric disturbance variables (eg EN 61000-4-5). Each power supply continuous withstand voltage test will cause extremely high load to the power supply. Therefore, unnecessary loading or damage to the power supply due to excessive test voltage should be avoided. If necessary, disconnect the gas discharge tube built into the device to use a higher test voltage. After successful completion of the test, reconnect the gas discharge tube. Please refer to the "LIHF240-23Bxx series power supply application manual" for specific operation methods; 2. \* The power supply has two converters with two different switching frequencies, Intermittent operation mode will be entered in light load or no load.

Functional Specific	cations						
Item	Operating Conditions	1	Min.	Тур.	Max.	Unit	
Daniela a antiol	Voltage between	Power on	0		0.8	\/DC	
Remote control	ON/OFF and SGND	Power off	4		20	VDC	
	Operation voltage	24V	-	21.6			
DC OK Dolan	Operation voltage	48V		43.2		V	
DC OK Relay	Release voltage	24V		19.2			
		48V	-	38.4	-		
AC OK signal	Input voltage 85 - 305	SVAC	3	-	5	VDC	
Current Sharing Accuracy		re connected in parallel, the ore than 50% of the rated load of a		±5		%	
		Normal output	LED ON				
		200%lo > Load > 125%lo		Green I	ight flashing		
LED signal	Main output status indicator	Power off (No AC power), under-voltage protection, remote off, short circuit/over-current protection, output voltage backflow	LED OFF				

**MORNSUN®** 





RS485-A, RS485-B

Based on ModBus communication protocol

RS485 communication

Note:1. \*Please refer to LIHF240-23Bxx Series Power Supply Application Manual for related functions, LED signal, control logic and usage instructions.;

2. \*When multiple prototypes are working in uniform current, the output voltage deviation of each prototype working separately shall not exceed 100mV.

<b>Environmental Characteri</b>	stics	
Item	Operating Conditions	Standard
High and Low Temperature Working	+85℃,-40℃	GB2423.1, IEC60068-2-1
Sinusoidal Vibration	10 - 500Hz, 2g, three directions of X, Y, Z axis	GB2423.10, IEC60068-2-6
Salt Mist	+35℃, 5%NACL, 48h	GB2423.17, IEC60068-2-11
Alternating Hot and Humid	+25℃, 95%RH - +60℃, 95%RH	GB2423.4, IEC60068-2-30
Low Temperature Storage	<b>-40</b> °C	GB2423.1, IEC60068-2-1
High Temperature Storage	<b>+85</b> ℃	GB2423.2, IEC60068-2-2
High Temperature Aging	<b>+60</b> ℃	GB2423.2, IEC60068-2-2
Normal Temperature Aging	<b>+25</b> ℃	GB2423.1, IEC60068-2-1
Temperature Shock	-40°C to +85°C	GB2423.22, IEC60068-2-14
Temperature Cycle	-25°C to +60°C	GB2423.22, IEC60068-2-14
Hot and Humid	+85℃,85%RH	GB2423.50, IEC60068-2-67
High Temperature Elevation	+60°C,54KPa	GB2423.26, IEC60068-2-41
Low Temperature Elevation	-25°C, 54KPa	GB2423.25, IEC60068-2-40
Constant Humid and Hot	+40℃, 95%RH	GB2423.3, IEC60068-2-78
Random Vibration	5 - 10Hz, ASD 0.3 - 10g <sup>2</sup> /Hz, three directions of X, Y, Z axis	GB/T 4798.2-2008, IEC60721-3-2
Sinusoidal Vibration Response	10 150 le le three directions of V V 7 mile	CD /T 11007 0000 IFC400FF 01 1
Sinusoidal Vibration Endurance Test	10 - 150Hz, 1g, three directions of X, Y, Z axis	GB/T 11287-2000, IEC60255-21-1
Sinusoidal Impulse Response	15g, pulse duration 11ms, three times in each direction of X,	CD/T 114527 1002 IFC40055 01 0
Sinusoidal Impact Endurance Test	Y, Z axis	GB/T 114537-1993, IEC60255-21-2
Packaging Drop	1m, one corner, three edges and six sides	GB2423.8, IEC68-2-32

Mechanical Specifications					
Case Material Metal (AL5052, SUS304)					
Dimensions	125.00mm x 130.00mm x 50.00mm				
Weight	950g (Typ.)				
Cooling Method	Free air convection				

Elec.	tromagnet	ic Compatibility (E	MC)
		General standard	CISPR32 EN55032 CLASS B
		In ductor // ight in ductor	IEC61000-6-3 AC port CLASS B, DC port CLASS A
		Industry/Light industry	IEC61000-6-4 AC port CLASS A
		Classification society*	GD22-2015 10kHz - 30MHz, EMC1
	CE	Power station/Subsation	IEC61850-3 CLASS A
			IEC62236-3-2 (EN50121-3-2) Output port CLASS A +20dB
		Railway	IEC62236-4 (EN50121-4) Output port CLASS A +20dB
EMI			IEC62236-5 (EN50121-5) AC port CLASS A
		General standard	CISPR32 EN55032 CLASS B
		Industry/Light industry	IEC61000-6-3 CLASS B
		Industry/Light industry	IEC61000-6-4 CLASS A
	RE	Classification society	GD22-2015 150KHz - 2GHz, EMC1
		Power station/Subsation	IEC61850-3 CLASS A
		Railway	IEC62236-3-2 (EN50121-3-2) CLASS B
		Kallway	IEC62236-4 (EN50121-4) CLASS B

**MORNSUN®** 





			IEC62236-5 (EN50121-5) CLASS B			
	Harmonic current	General standard	IEC/EN6100-3-2 Class A and Class D			
			IEC62236-3-2 (EN50121-3-2) 50Hz - 2KHz			
		Railway	IEC62236-4 (EN50121-4) 50Hz - 2KHz			
		General Standard	IEC/EN 61000-4-2 Output port Contact ±8KV/Air ±15KV	perf. Criteria A		
			IEC61000-6-1 Contact ±4KV/Air ±8KV	perf. Criteria A		
		Industry/Light industry	IEC61000-6-2 Contact ±4KV/Air ±8KV	perf. Criteria A		
		Wind power	NB/T 31017-2011 Contact ±6KV/Air ±8KV	perf. Criteria A		
		Classification society	GD22-2015 Contact ±6KV/Air ±8KV	perf. Criteria A		
	ESD	Power	IEC61850-3 Contact ±6KV/Air ±8KV	perf. Criteria A		
		station/Subsation	IEC61000-6-5 Contact ±6KV/Air ±8KV	perf. Criteria A		
			IEC62236-3-2 (EN50121-3-2) Contact ±6KV/Air ±8KV	perf. Criteria A		
		Railway	IEC62236-4 (EN50121-4) Contact ±6KV/Air ±8KV	perf. Criteria A		
		Railway	IEC62236-5 (EN50121-5) Contact ±6KV/Air ±8KV	perf. Criteria A		
		General standard	IEC/EN 61000-4-3 10V/m	perf. Criteria A		
		Serieral significator	IEC61000-6-1 80M - 1GHz, 3V/m; 1.4G - 6GHz, 3V/m	perf. Criteria A		
		Industry/Light industry	IEC61000-6-2 80M - 1GHz, 10V/m; 1.4G - 2GHz, 3V/m; 2 -	•		
		,, ,	2.7GHz, 1V/m	perf. Criteria A		
		Wind power	NB/T 31017-2011 80M - 1GHz, 10V/m	perf. Criteria A		
		Classification society	GD22-2015 80M - 2GHz, 10V/m	perf. Criteria A		
	RS	Power	IEC61850-3 80M - 3GHz, 10V/m	perf. Criteria A		
		station/Subsation	IEC61000-6-5 80M - 1GHz, 10V/m; 1G - 2.7GHz, 3V/m; 2.7G - 6GHz, 1V/m	perf. Criteria A		
			IEC62236-3-2 (EN50121-3-2) 80M - 1GHz, 20V/m; 1.4GHz - 2GHz, 10V/m; 2G - 2.7GHz, 5V/m; 2.7G - 6GHz, 3V/m	perf. Criteria A		
		Railway	IEC62236-4 (EN50121-4) 80M - 800MHz, 10V/m; 800MHz - 1GHz, 20V/m; 1.4G - 2GHz, 10V/m; 2G - 2.7GHz, 5V/m; 5.1G - 6GHz, 3V/m	perf. Criteria A		
EMS			IEC62236-5 (EN50121-5) 80M - 800MHz, 10V/m; 800MHz - 1GHz, 20V/m; 1.4G - 2GHz, 10V/m; 2G - 2.7GHz, 5V/m; 5.1G - 6GHz, 3V/m	perf. Criteria A		
		General standard	IEC/EN 61000-4-4 ±4KV	perf. Criteria A		
		Industry/Light industry	IEC61000-6-1 DC input, output and signal contral port: ±0.5KV, 5/100KHz, AC input and output port: ±1KV, 5/100KHz	perf. Criteria A		
		aas, agaas,	IEC61000-6-2 DC input, output and signal contral port: ±0.5KV, 5/100KHz, AC input and output port: ±1KV, 5/100KHz	perf. Criteria A		
		Wind power	NB/T 31017-2011 Power source and PE: ±4KV, 5/100KHz, signal and contral port: ±2KV, 5/100KHz (Capacitive coupling clamp)	perf. Criteria A		
		Classification society	GD22-2015 ±1KV, 5KHz; ±2KV, 2.5KHz  IEC61850-3 AC, DC input output port, signal port, ground	perf. Criteria A		
		Power	port: ±2KV	perf. Criteria A		
	EFT	station/Subsation	IEC61000-6-5 AC, DC input output port: ±2KV; signal port: cable<3m: ±2KV, cable>3m: ±4KV	perf. Criteria A		
			IEC62236-3-2 (EN50121-3-2) Signal, contral port: ±2KV, 5KHz (Capacitive coupling clamp), AC, DC input output port: ±2KV, 5KHz	perf. Criteria A		
		Railway	IEC62236-4(EN50121-4) Signal, contral port: ±2KV, 5KHz (Capacitive coupling clamp), AC, DC input output port: ±2KV, 5KHz, PE ground/shell: ±1KV, 5KHz	perf. Criteria A		
			IEC62236-5(EN50121-5) Signal, contral port: ±2KV, 5KHz Capacitive coupling clamp), AC, DC input output port: ±4KV, 5KHz, PE ground/shell: ±1KV, 5KHz	perf. Criteria A		
		General standard	IEC/EN 61000-4-5 AC input port: ±4KV/±6KV	perf. Criteria A		
	Surge	Industry/Light industry	IEC61000-6-1 DC input and output port: ±0.5KV/±1KV, AC input and output port: ±1KV/±2KV, signal and contral port: ±1KV common mode	perf. Criteria A		
			IEC61000-6-2 DC input and output port: ±0.5KV/±0.5KV, AC input and output port: ±1KV/±2KV, signal and contral port: ±1KV common mode	perf. Criteria A		

**MORNSUN®** 





	Wind power	NB/T 31017-2011 AC, DC power source port: ±1KV/±2KV	perf. Criteria A
	Classification society	GD22-2015 AC, DC power source port: ±0.5KV/±1KV	perf. Criteria A
	Power	IEC61850-3 AC, DC power source, signal port: ±1KV/±2KV, power carrier communication port: ±2kV/4kV	perf. Criteria A
	station/Subsation	IEC61000-6-5 Signal, contral port: ±1KV common mode (If the cable<10m, no test is required), DC input and output port: ±1KV/±2KV, AC input and output port: ±2KV/4KV	perf. Criteria A
		IEC62236-3-2 (EN50121-3-2) Battery port, AC input port: $\pm 1 \text{KV}/\pm 2 \text{KV}$ (42 $\Omega$ output impedance)	perf. Criteria A
	Railway	IEC62236-4 (EN50121-4) DC power source, signal, contral port: $\pm 1 \text{KV}/\pm 2 \text{KV}$ (42 $\Omega$ output impedance), AC power source port: $\pm 1 \text{KV}/\pm 2 \text{KV}$	perf. Criteria A
		IEC62236-5 (EN50121-5) DC input and output, signal, contral port: $\pm 1 \text{KV}/\pm 2 \text{KV}$ , AC input and output port: $\pm 2 \text{KV}/\pm 4 \text{KV}$	perf. Criteria A
	General standard	IEC/EN61000-4-6 10Vr.m.s	perf. Criteria A
	In all later // i askt in all later	IEC61000-6-1 AC input and output, signal, contral port: 0.15M - 80MHz, 3V	perf. Criteria A
	Industry/Light industry	IEC61000-6-2 AC input and output, signal, contral port: 0.15M - 80MHz, 10Vr.m.s	perf. Criteria A
	Wind power	NB/T 31017-2011 0.15M - 80MHz, 10Vr.m.s	perf. Criteria A
CS	Classification society	GD22-2015 0.15M - 80MHz, 10Vr.m.s, Low frequency conduction immunity: AC input port, harmonic < 15 times 10%Un, harmonic = 15 - 100 times, from 10%Un to 1%Un, harmonic = 100 - 200 times, 1%Un; DC input port, 10%Un, 50 - 10kHz, apply power≤2W (The applied voltage can be reduced)	perf. Criteria A
	Power	IEC61850-3 AC, DC input, output, signal, contral port, PE port: 0.15M - 80MHz, 10Vr.m.s	perf. Criteria A
	station/Subsation	IEC61000-6-5 AC, DC input, output, signal, contral port: 0.15M - 80MHz, 10Vr.m.s	perf. Criteria A
	Railway	IEC62236-3-2 (EN50121-3-2) AC/Battery input, signal, contral port: 0.15M - 80MHz, 10Vr.m.s	perf. Criteria A
		IEC62236-4 (EN50121-4) AC, DC input, output, signal, contral port: 0.15M - 80MHz, 10Vr.m.s	perf. Criteria A
		IEC62236-5 (EN50121-5) AC, DC input, output, signal, contral port, PE port: 0.15M - 80MHz, 10Vr.m.s	perf. Criteria A
	General standard	IEC/EN61000-4-11 0%, 70%	perf. Criteria B
Voltage dips, short	Industry/Light industry	IEC61000-6-1 0%, 0.5/1 period, 70%, 25/30 period @50/60Hz, 0%, 250/300 period @50/60Hz	perf. Criteria B and
nterruptions and voltage	industry/Light industry	IEC61000-6-2 0%,1 period, 0%, 250/300 period @50/60Hz, 40%, 10/12 period @50/60Hz	perf. Criteria B and
variations mmunity	Power	IEC61850-3 AC input and output port: 100%, 5/50 period, DC input and output port: 100%, 0.05s	perf. Criteria B
,	station/Subsation	IEC61000-6-5 AC input and output port: 70%, 1 period, 40%, 50 period, 0%, 5 period, 0%, 50 period	perf. Criteria B
	General standard	IEC/EN61000-4-8 100A/mcontinuous, 1KA/m 1s	perf. Criteria A
	Industry/Light industry	IEC61000-6-1 50/60Hz, 30A/m	perf. Criteria A
Power frequency magnetic	y	IEC61000-6-2 50/60Hz, 30A/m	perf. Criteria A
	Power	IEC61850-3 100A/mcontinuous, 1KA/m 1s	perf. Criteria A
field	station/Subsation	IEC61000-6-5 100A/mcontinuous, 1KA/m 1s	perf. Criteria A
	Railway	IEC62236-4 (EN50121-4) 50Hz, 100A/m, DC 300A/m	perf. Criteria A
	Nanway	IEC62236-5 (EN50121-5) 50Hz, 100A/m, DC 300A/m	perf. Criteria A
Intercom inter	ference test	MS-SOP-DQC-007	perf. Criteria B

Note: 1. \*perf. Criteria:

A: The equipment shall continue to operate as intended without operator intervention;


B: After the test, the equipment shall continue to operate as intended without operator intervention;


C: Loss of function is allowed, provided the function is self-recoverable, or can be restored by the operation of the controls by the user in accordance with the manufacturer's instructions;


<sup>2. \*</sup>With our filter module model: FC-L06I-CCS supporting shipment.




### **Product Characteristic Curve**













#### Over-current/ Short circuit protection curve






















Figure 11





















Note:1. All curves are for 24V output, measured at input 230VAC, 50Hz, output Io, ambient temperature 25°C, unless otherwise stated;

- 2. With an AC input voltage between 85-100VAC and a DC input between 120 140VDC the output power must be derated as per the temperature derating curves;
- 3. FIG. 1, 2, 4 and 5 are carried out under the condition of 25 CFM at a high temperature of 75  $\sim$  85  $^{\circ}$ C;
- 4. This product is suitable for applications using natural air cooling, for applications in closed environment please consult Mornsun FAE.







**Dimensions and Recommended Layout** 


LIHF240-23Bxx Series



#### Top View







#### THIRD ANGLE PROJECTION



Pin	–Out
Pin	Mark
1	-Vo
2	-Vo
3	-Vo
4	+Vo
5	+Vo
6	<b>(</b>
7	AC(N)
8	AC(L)

Signal	Pin-Out	
	Pin	Mark
	S-1	DC
S-1 🖽	S-2	OK
S-2	S-3	RS485-A
S-3 H S-4 H S-5 H S-6 H S-7 H S-8 H S-9	S-4	RS485-B
	S-5	ON/OFF
	S-6	SGND
	S-7	AC OK
	S-8	PCS
	S-9	PCS

Note:

Unit: mm[inch]

Wire range: Input: 22-10AWG(12-10AWG for pin6)

Output: 24V: 14-10AWG 48V: 18-10AWG Signal: 24-16AWG

Tightening torque: Max 0.5N · m

Mounting rail: TS35, rail needs to connect safety ground

General tolerances:  $\pm 1.00[\pm 0.039]$ 



#### Note:

- 1. For additional information on Product Packaging please refer to <a href="www.mornsun-power.com">www.mornsun-power.com</a>. Packaging bag number: 58220314;
- 2. Unless otherwise specified, parameters in this datasheet were measured under the conditions of Ta=25°C, humidity <75% RH with nominal input voltage and rated output load;
- 3. The room temperature derating of  $5^{\circ}$ C/1000m is needed for operating altitude greater than 2000m;
- 4. All index testing methods in this datasheet are based on our company corporate standards;
- In order to improve the efficiency at high input voltage, there will be audible noise generated, but it does not affect product performance and reliability;
- 6. We can provide product customization service, please contact our technicians directly for specific information;
- 7. Products are related to laws and regulations: see "Features" and "EMC";
- 8. The out case needs to be connected to PE ( ) of system when the terminal equipment in operating;
- 9. Key to adjust,  $\triangle$  key for voltage increase,  $\nabla$  key for voltage decrease;
- 10. Our products shall be classified according to ISO14001 and related environmental laws and regulations, and shall be handled by qualified units.

### Mornsun Guangzhou Science & Technology Co., Ltd.

Address: No. 5, Kehui St. 1, Kehui Development Center, Science Ave., Guangzhou Science City, Huangpu District, Guangzhou, P. R. China Tel: 86-20-38601850 Fax: 86-20-38601272 E-mail: info@mornsun.cn www.mornsun-power.com

# LIHF240-23Bxx Series Power Supply Application Notes

### Content

I. Mechanical Specification	12
1.1 Input terminal (CN1)	12
1.2 Output terminal (CN2)	13
1.3 Signal connection terminal (CN5)	13
1.4 Status display LED	14
1.5 Output voltage regulation	14
2. Circuit block diagram	12
3. Function Manual	16

**MORNSUN®** 


LIHF240-23Bxx Series



3.1 Input Requirements	16
3.2 Output Requirements	16
3.3 Power Failure Holding Time And AC OK Advance Warning Time	16
3.4 Output Over-Voltage Protection (OVP)	17
3.5 Transient Peak Current Function	18
3.6 Output Over-Current and Short Circuit Protection (OCP And SCP)	18
3.7 Over Temperature Protection (OTP)	18
3.8 Output Power Derating	18
3.9 Remote Control Switch	19
3.10 DC_OK Signal	19
3.11 Used in series	20
3.12 Work in parallel	20
3.13 PC Monitoring	21
3.14 Back Voltage Load	24
4. Installation Requirements	24
4.1 Safety Introduction	24
4.2 Safety Requirements	25
4.3 High-voltage Holding Test	25
4.4 Installation Methods	25
1 Mechanical Specification	

١.	IVICCI		Calloll

	Structure Instruction
1	Input terminal (CN1)
2	Output terminal (CN2)
3	Mode status display LED
4	Voltage adjustment button




5	Signal connection terminal (CN5)
6	Power indicating LED

Figure 1: LIHF240-23Bxx Appearance Information

### 1.1 Input Terminal (CN1)

3 Position 6.35 mm Barrier Terminal Blocks is used as Input terminal.



Line size: 22-10AWG Torque: 0.5Nm


Pin	Features
L	Live
N	Neutral
	Protective Earth

### 1.2 Output Terminal (CN2)

**MORNSUN®** 



6 Position 6.35 mm Barrier Terminal Blocks is used as Output terminal.



Pin	Features
+Vo	Positive output
-Vo	Negative output

Line size: 14-10 AWG Torque: 0.5 Nm

### 1.3 Signal Connection Terminal (CN5)


0:1	Pin-Out	
Signal	Pin	Mark
	S-1	DC
S-1 🖽	S-2	OK
S-2 S-3 S-4 S-5 S-6 S-7 S-8 S-9	S-3	RS485-A
	S-4	RS485-B
	S-5	ON/OFF
	S-6	SGND
	S-7	AC OK
	S-8	PCS
	S-9	PCS

Line size: 24-16 AWG Torque: 0.5 Nm

### 1.4 Status Display LED

**MORNSUN®** 














#### Power status indicator LED

LED	State
LED1 ON	DC-OK, Output Power≤50%
LED1-LED2 ON	75%≥Output Power>50%
LED1-LED3 ON	100%≥Output Power>75%
LED1-LED4 ON	Output Power>100%
LED4 Flashing	200%≥Output Power>125%

#### Mode status indicator

LED	State
LED5 ON	l2x, 2 times peak current
LED6 ON	lóx, 6 times transient peak current


### 1.5 Output Voltage Regulation



Model	Rated Output Voltage	Output Voltage Adjustable Range
LIHF240-23B24	24VDC	24VDC-28VDC
LIHF240-23B48	48VDC	48VDC-55VDC



### 2. Circuit Block Diagram



### 3. Function Manual


### 3.1 Input Requirements

The AC input voltage and DC input voltage must be within the defined voltage range (refer to the data sheet), otherwise the power supply may not work properly or even fail. An 8A/250VAC fuse is connected to the power module. To better protect the power module, you are advised to use a circuit breaker larger than 8A (Strengthen protection, not necessary access requirements).

### 3.2 Output Requirements

At any output voltage value, if it is necessary to operate normally, the highest pull current and power must not exceed the rated specified value, and the output current must not exceed the maximum output current value.

### 3.3 Power Failure Holding Time And AC OK Advance Warning Time




**MORNSUN®** 



Item	Working conditions			Тур.	Max.	Unit
Power-off hold time	115VAC/230VAC, full load		I	22	-	ms
AC OK Advance warning time	115VAC/230VAC, full load	The warning time is higher than Uo*90%	-	15	-	ms


### 3.4 Output Over-Voltage Protection (OVP)

The main circuit output will be off when the output voltage reaches the over-voltage protection value. When it occurs, the output enters the hiccup mode with 5s. After the abnormal removed, the output returns to normal.



### 3.5 Transient Peak Current Function

Transient peak current means that the output can work at 600% lo constant current. When the output is short circuit or needs a lot of current, it can work at 600% lo constant current for 3 times for 15ms (typ.), which can provide long-term short-circuit protection and self-recovery.



Note: The function of the 600% transient peak current function can be turned on or off in the following two ways, with a state of up to 200% current limit after being turned off:

Method 1: Hold down the two buttons of voltage regulation for 3s at the same time, and the LED display changes from I6x to I2x;

If you hold down 3s again, you can turn on the 600% peak current function again.

Method 2: The function can be turned on or off by writing the corresponding instruction to address 65 through Modbus communication:




Site	Data Type	Variable Name	Function Declaration
65	Uint16	Control_Mode	Control mode: 1: Turn on 600% transient peak current 0: Turn off 600% transient peak current

Name	Value	Unit	Read	Command	Write	Block	Address	Count	Offset	Digit	Coefficient
Control Mode	0X0001		Read		Write	RW	65	1	0	16	1

### 3.6 Output Over-Current And Short Circuit Protection (OCP And SCP)

Static power mode: When the output current exceeds 100% of the rated output current but does not exceed 125% of the rated output current, the output enters the static power mode. The static power of the product is 125%lo (typ.), which can work for a long time and does not enter the protection state. Dynamic power mode: When the output current exceeds 125% of the rated output current and does not exceed 200% of the rated output current, the output will enter the dynamic power mode. The dynamic power point of the product is 200%lo (typ.), and the product will enter the static power mode after working for 5S (typ.). The working time and shutdown time can be self-adapted according to different load conditions, which can provide long-term protection and self-recover.





### 3.7 Over Temperature Protection (OTP)

When the ambient temperature of the power supply exceeds the rated temperature for a period of time, the power supply will turn off the output and enter the hiccup state. After the ambient temperature drops to the set value, the power supply will resume normal operation.

### 3.8 Output Power Derating

When the input voltage is greater than 100VAC (or 140VDC), only need to derate according to the temperature derating curve;







**MORNSUN®** 



When the input voltage is lower than 100VAC (or 140VDC), the output power will be derated according to the following input voltage derating curve requirements after the temperature derating.



### 3.9 Remote Control Switch



ON/OFF (S-5) and SGND(S-6)Switch	Output Status
DC Source power supply voltage is less than 0.8VDC	Normal output
DC Source supply voltage is greater than 4VDC less than 20VDC	Output Off

If the power module is connected to the power supply, the ON and OFF of its output can be controlled by applying an external voltage between the ON/OFF signal pin and SGND.

### 3.10 DC\_OK Signal

The DC\_OK signal is used to monitor whether the power supply is working normally, at the first and second pins of the signal terminals. When the output voltage is greater than 90% of the rated output voltage, the DC\_OK signal acts, the DC\_OK at the output terminal is connected, and LED1 lights up. When the output voltage is less than 85% of the rated output voltage, the DC\_OK of the output terminal is disconnected, and LED1 is off.

**MORNSUN®** 





#### 3.11 Used In Series


The same type of power supply can be connected in series to increase the output voltage. As long as the total output voltage does not exceed 150Vdc, you can connect as many power supplies as you need. Voltages in excess of 60Vdc are no longer considered Safety Extra Low Voltage Circuits (SELV) and can therefore be dangerous. When installing such voltages, it must be protected against touch.

Please avoid generating feedback voltage to the output terminals (eg from a decelerating motor or battery).

Keep a 15mm (left/right) installation gap between the two power supplies and avoid installing the power supplies on top of each other. Do not connect the power supplies in series in an installation orientation other than the standard installation orientation (input terminals down).

Note that leakage current, electromagnetic interference, inrush current and harmonics will increase when multiple power supplies are used.

Refer to the figure below for the wiring method:




#### 3.12 Work In Parallel

The PSU supports 6 PCS in parallel current equalization.

The current sharing bus (PCS) between multiple machines can be short connected to each other, and can be connected by jumper wire.

The output voltage difference of each single module is less than 100mV, which can obtain a better line-end output voltage and current sharing comprehensive effect. The connection mode of the current-sharing function is shown in the figure below:





Note: 1. When used in parallel, the number of parallel modules cannot exceed 6 PCS.

2. When the power modules work in parallel, there is an active current sharing circuit inside to ensure that the current between each module remains balanced.

Active current sharing circuit adopts automatic master-slave current sharing mode. Each power module has a current sharing bus signal (PCS). When working in parallel, the current sharing buses of all power modules must be connected together. It can be connected through jumper wires. The power terminal has reserved two internal connected PCS ports of the current sharing bus signal, namely, two pins of port bit 8 and 9, which can be connected to one of the pins in use.

The output voltage of each power module will affect the current sharing accuracy. The output voltage of the power module is rated voltage  $\pm$  100mV. In practical applications, if the output voltage value needs to be adjusted, the output voltages of all parallel power modules need to be adjusted to the same voltage. The recommended voltage range is: target voltage value  $\pm$  100mV.

After the output load of each power module is greater than 50% of the rated load, the current sharing accuracy is required to be  $\pm 5\%$ . The calculation formula of current sharing is:

Power supply 1's average accuracy = 
$$\frac{Io_1 - (Io_1 + Io_2)/2}{(Io_1 + Io_2)/2} *100\%$$


Power supply 2's average accuracy= 
$$\frac{Io_2-(Io_1+Io_2)/2}{(Io_1+Io_2)/2}*100\%$$

lo<sub>1</sub>: The output current value of the power supply 1 in the parallel power module.

lo<sub>2</sub>: The output current value of the power supply 2 in the parallel power module.

### 3.13 PC Monitoring

In a parallel system, if you need to identify the information of the power modules, you need to monitor each parallel power module by the host computer. The connection diagram is as follows:



**MORNSUN®** 





That is, connect the RS485-A and RS485-B of the signal terminals to the USB to interface module. The upper computer "MThings" of Modbus can be used to read and configure the power supply products, or the relevant instructions can be sent directly through the corresponding address.

Function name and corresponding address, quantity and coefficient of ModBus are shown below:

ID	Name	Value	Unit	Read	Command	Write	Block	Address	Count	Offset	Digit	t Coefficient
1	SN	20221111001110		Read		Write	RW	0	32	0	512	1
2	Product Type	LIHF240-23B24		Read	227	Write	RW	32	32	0	512	1
3	Firmware Version	3		Read		Write	RW	64	1	0	16	1
4	Control Mode	0X0001		Read	<b>5</b> 78	Write	RW	65	1	0	16	1
5	MODBUS ID	0		Read	22.	Write	RW	66	1	0	16	1
6	MODBUS Baud Rate SET	1		Read		Write	RW	67	1	0	16	1
7	Run Time	0.381152	h	Read	==	Write	RW	72	2	0	32	0.000277
8	Vo Set	24.000000	V	Read		Write	RW	74	2	0	32	1
9	Input Voltage	228.412827	V	Read	223	Write	RW	76	2	0	32	1
10	Output Voltage	24.079004	V	Read	200	Write	RW	80	2	0	32	1
11	Output Current	9.890471	Α	Read		Write	RW	82	2	0	32	1
12	Output Power	238.158234	W	Read	<b>7</b> 70	Write	RW	84	2	0	32	1
13	Inside Temperature	84.000000	°C	Read	223	Write	RW	86	2	0	32	1
14	Output State1	0X0003		Read	240	Write	RW	88	1	0	16	1
15	Warning State2	0X0000		Read	==	Write	RW	89	1	0	16	1
16	Remaining Service Life	43676.978848	h	Read	77	Write	RW	90	2	0	32	0.000277
17	Remote ON/OFF	1		Read	223	Write	RW	128	1	0	16	1
18	Running Time from ACON	185	S	Read	200	Write	RW	130	2	0	32	1
19	Output OVP Times	0		Read	75	Write	RW	132	1	0	16	1
20	Output OCP Times	0		Read	552	Write	RW	133	1	0	16	1
21	Input UVP Times	0		Read	223	Write	RW	136	1	0	16	1
22	Input OVP Times	0		Read	200	Write	RW	137	1	0	16	1
23	OTP Times	0		Read		Write	RW	138	1	0	16	1

Note: 1. Open the upper computer software, import the configuration, click batch read to obtain the related information. In the command column, input relevant information can be configured, such as the output voltage configuration.

2. The default baud rate is 9600bps. Configure the baud rate as follows.


Configuration instructions	Baud rate (bps)
1	9600
2	38400
3	57600
4	115200

- 3. After the serial port communication address (ModBus ID) is configured, power off the device and restart it to take effect one minute later.
  - 4. Function and data format definition of MODBUS communication register.

In byte type data 4, the high half word comes first and the low half word comes last

Address	Data Type	Name Of Variable	Function Description	Read And Write Permissions
0-31	Char	SN_MODEL	Product serial number	Read-Only
32-63	Char	Product_MODEL	Product Model Number	Read-Only

**MORNSUN®** 





64	Uint16	Version	Product firmware version	Read-Only
65	Uint16	control_mode	Control mode: 1: Turn on 600% transient peak current 0: Turns off 600% transient peak current	Read/Write
66	Uint16	Add	Serial communication address (ModBus ID)	Read/Write
67	Uint16	Baud	Baud rate of serial port communication	Read/Write
72 73	Uint32	RUNTIME	Accumulated running time (unit "s", converted to "h" by the host computer/user)	Read-Only
74 75	Float32	Set_VOL	Output voltage configuration	Read/Write
76 77	Float32	VAC_RMS	AC input voltage	Read-Only
80 81	Float32	Vout	Output voltage	Read-Only
82 83	Float32	lout	Output current current	Read-Only
84 85	Float32	Pout	Power output	Read-Only
86	Float32	Temperature	Internal temperature	Read-Only
88	Uint16	State1	Output State1 (0~3byte): DC-OK (0), AC-OK (1), OVP (2), OCP (3); 1 for OK or Protection State, 0 for NOK	Read-Only
89	Uint16	State2	Warning State2 (0~5byte): Input UV Warning (1), Input OV Warning (2), Remaining Service Life Warning (3), Over Temperature Warning (4), Failure Warning (5); 1 for Warning, 0 for Normal	Read-Only
90	Float32	Life	Remaining Service Life	Read-Only

**MORNSUN®** 



91			(unit "s", converted to "h" by the host computer/user)	
128	Uint16	ON/OFF	Remote ON/OFF, 1 for ON, 0 for OFF	Read/Write
130	Llimton	DUNUNICTIME	running time	Donal Only
131	Uint32	RUNINGTIME	(unit "s", converted to "h" by the host computer/user)	Read-Only
132	Uint16	OVP_TIMES	Output OVP Times	Read/Write for Reset to zero
133	Uint16	OCP_TIMES	Output OCP Times	Read/Write for Reset to zero
136	Uint16	INPUT_UVP_TIMES	Input UVP Times	Read/Write for Reset to zero
137	Uint16	INPUT_OVP_TIMES	Input OVP Times	Read/Write for Reset to zero
138	Uint16	OTP_TIMES	OTP Times	Read/Write for Reset to zero


### 3.14 Back Voltage Load

Loads such as decelerating motors, inductors can feed voltage back into the power supply. This property is also known as feedback voltage resistance or resistance to opposing electromagnetic forces.

LIHF240-23B24: ①The feedback voltage within 30V, product will not shut down, and it will automatically recover after no feedback voltage in; ②If the feedback voltage exceeds 30V and is less than 35V, the output will be shut down and restart after 5S.

LIHF240-23B48: ①The feedback voltage within 57V, product will not shut down, and it will automatically recover after no feedback voltage in; ②If the feedback voltage exceeds 57V and is less than 63V, the output will be shut down and restart after 5S.

The power supply is resistant to the voltage that the load feeds back into the power supply and will not fail regardless of whether the power supply is on or off. The following function diagram:



Maximum allowable feedback voltage				
Model	Maximum feedback voltage			
LIHF240-23B24	35VDC			
LIHF240-23B48	63VDC			

### 4. Installation Requirements

### 4.1 Safety Introduction

WARNING: RISK OF ELECTRIC SHOCK DURING HIGH VOLTAGE WORKING WITH THIS EQUIPMENT

 After the power module is disconnected from the input AC or DC power, leave it for at least one minute before starting to operate it.

**MORNSUN®** 

#### LIHF240-23Bxx Series



- When installing the input cable to the power module, first connect the ground terminal, and then connect the L and N cables.
- When removing the input wire, first remove the L wire and N wire, and then remove the ground wire
- When disassembling and assembling, make sure that no objects fall into the inside of the power module.
- Be careful of high temperature burns
- After the power module works in a high temperature environment, wait for its shell to cool before
  operating it.
- This product needs to be installed by professionals and needs to be used with other equipment.


### 4.2 Safety Requirements

When installing, pay attention to the primary side and the protective ground. The creepage distance and electrical clearance of the primary side and the secondary side meet the safety requirements, refer to EN/UL61010.

#### 4.3 Withstand Pressure Test

The screw at the side mark of the casing should be removed when the product is tested for pressure resistance .

The built-in gas discharge tube protects the power supply from asymmetric interference variables (e.g. EN 61000-4-5). Each power supply sustained voltage test will cause a very high load on the power supply. Therefore, unnecessary load or damage to the power supply caused by high test voltage should be avoided. Disconnect the device's built-in gas discharge tube if necessary to use a higher test voltage. Reconnect the gas discharge tube after successful completion of the test.





**Danger:** Using the wrong gas discharge tube bolts can result in an electric shock hazard or power supply damage. To connect the gas discharge tube, use only the gas discharge tube bolts originally installed in the power supply.

Disconnect the gas discharge tube by performing the following steps.

- 1. Disconnect the power supply to the unit;
- 2. Completely unscrew the bolt to ensure that the gas discharge tube is connected to a safe position. Now that the gas discharge tube has been disconnected, it no longer functions;
  - Perform sustained voltage test on the power supply;
  - 4. After successful voltage test, screw the gas discharge tube back to the power supply completely.


**MORNSUN®** 




### 4.4 Installation Method

Installation direction: When installing, the port of the output end should be upward, and the port of the input end should be downward. (See below)

Note: Pay attention to the temperature rise of the device in different installation modes. Derate the device according to the actual situation.





Various Installation Methods






① Mounting the universal DIN rail power supply. (Forward Installation. Label is needed to be removed)




② Mounting the universal DIN rail power supply.(Reverse Installation. Label is needed to be removed)





- ① After connecting the terminal to the connecting wire, lay and align the connecting wire.
- ② Tie up the stripes with cables and fix the connecting wires through the gaps on the both sides of the shell.




Rotate the installation position (0° Z-Axis)









Rotate the installation position (90° Z–Axis)










Rotate the installation position (180° Z–Axis)



















(90° X-Axis)






1	Product	1PCS
2	Phillips screwdriver Slotted screwdriver	1PCS
3	TS35/7.5 or TS35/15	1PCS
4	24-10AWG Wire	/ PCS
5	The content is for re Regarding the actual wire dia torque, refer to the dime	ameter and tighten




#### Installation steps ①-②

1) Clamp the buckle of the product into the TS35 DIN rail.



②Push the product vertically towards the TS35 DIN rail until hearing the sound of the buckle snapping into it.

#### Disassembly Steps 3-4



③After inserting the slotted screwdriver into the square groove at the bottom of the buckle, push the slider of the buckle downward in the direction shown in the figure.

④Hold the bottom of the product and push it outwards while pushing down the slider, then lift the product up to take the product out of the DIN rail.


# AC/DC 240W DIN-Rail Power Supply LIHF240-23Bxx Series



Wiring / Unwiring Steps 5-6



⑤Turn the Phillips screwdriver to the left to loosen the terminal screws, insert the head of the wire into the bottom of the terminal, and then turn the screwdriver to the right to tighten the terminal screws



⑥Turn the Phillips screwdriver to the left to loosen the terminal screw and pull the wire out of the bottom of the terminal